








Entry Lights Control System (MICU) Input Test**NOTE:**

- Refer to the Electrical Wiring Diagrams for the location of the under-dash fuse/relay box connectors.
- Before testing, make sure the No. A28 (7.5 A) and No. A29 (10 A) fuses in the under-hood fuse/relay box, and the No. B5 (7.5 A) fuse in the under-dash fuse/relay box are OK.

1. Turn the ignition switch to LOCK (0).
2. [Disconnect under-dash fuse/relay box connectors A, B, D, N, P, W, and X.](#)

NOTE: All connector views are shown from wire side of female terminals.

CONNECTOR B (44P)**CONNECTOR D (32P)****CONNECTOR A (5P)****CONNECTOR N (13P)****CONNECTOR P (20P)****CONNECTOR W (24P)****CONNECTOR X (10P)**

- Inspect the connector and socket terminals to be sure they are all making good contact:

- If the terminals are bent, loose, or corroded, repair them as necessary, and recheck the system.
- If the terminals are OK, go to step [4](#).

4. With the connectors still disconnected, do the following input tests:

- If any test indicates a problem, find and correct the cause, then recheck the system.
- If all the input tests prove OK, go to step [5](#).

Cavity	Wire	Test condition	Test: Desired result	Possible cause if desired result is not obtained
P7 P12	LT BLU LT GRN	Under all conditions	Connect terminals P7 and D18, and terminal P12 and body ground with jumper wires: The ignition key light should come on.	<ul style="list-style-type: none"> ● Blown No. A28 (7.5 A) fuse in the under-hood fuse/relay box ● Faulty ignition key switch ● An open or high resistance in the wire
N6	PNK	Ceiling light switch in middle position (and front individual map light switch in ON position and interior light switch in DOOR position)*	Connect terminals D18 and N13, and terminal N6 and ground with jumper wires: The ceiling light (and front individual map lights)* should come on.	<ul style="list-style-type: none"> ● Blown bulb ● Faulty ceiling light ● Faulty front individual map lights* ● An open or high resistance in the wire

*: With moonroof

5. Reconnect the connectors to the under-dash fuse/relay box; do the following input tests:

- If any test indicates a problem, find and correct the cause, then recheck the system.
- If all the input tests prove OK, the MICU must be faulty; [replace the under-dash fuse/relay box](#).

Cavity	Wire	Test condition	Test: Desired result	Possible cause if desired result is not obtained
A3	BLU	Ignition switch ON (II)	Measure the voltage to ground: There should be battery voltage.	An open or high resistance in the wire
D28	WHT	Under all conditions	Measure the voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> ● Blown No. A29 (10 A) fuse in the under-hood fuse/relay box ● An open or high resistance in the wire
D18	LT BLU	Under all conditions	Measure the voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> ● Blown No. A28 (7.5 A) fuse in the under-hood fuse/relay box ● An open or high resistance in the wire
W6	BLK	In all ignition switch positions	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> ● Poor ground (G501) ● An open or high resistance in the ground wire
B32	BLK	In all ignition switch positions	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> ● Poor ground (G602) ● An open or high resistance in the ground wire
B40	GRN	Driver's door open	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> ● Faulty driver's door switch ● Faulty driver's door switch ground ● An open or high resistance in the wire
		Driver's door closed	Measure the voltage to ground: There should be about 5 V.	<ul style="list-style-type: none"> ● Faulty driver's door switch ● A short to ground in the wire

Cavity	Wire	Test condition	Test: Desired result	Possible cause if desired result is not obtained
B29	LT GRN	Front passenger's door open	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> Faulty front passenger's door switch Faulty front passenger's door switch ground An open or high resistance in the wire
		Front passenger's door closed	Measure the voltage to ground: There should be about 5 V.	<ul style="list-style-type: none"> Faulty front passenger's door switch A short to ground in the wire
B33	BRN	Left rear door open	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> Faulty left rear door switch Faulty left rear door switch ground An open or high resistance in the wire
		Left rear door closed	Measure the voltage to ground: There should be about 5 V.	<ul style="list-style-type: none"> Faulty left rear door switch A short to ground in the wire
B34	GRY	Right rear door open	Check for continuity to ground: There should be continuity.	<ul style="list-style-type: none"> Faulty right rear door switch Faulty right rear door switch ground An open or high resistance in the wire
		Right rear door closed	Measure the voltage to ground: There should be about 5 V.	<ul style="list-style-type: none"> Faulty right rear door switch An open or high resistance in the wire
X5	LT GRN	Driver's door lock knob switch in LOCK	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> Faulty driver's door lock knob switch Poor ground (G502) or an open in the ground wire An open or high resistance in the wire
		Driver's door lock knob switch in UNLOCK	Measure the voltage to ground: There should be about 5 V.	<ul style="list-style-type: none"> Faulty driver's door lock knob switch A short to ground in the wire
X4	WHT	Driver's door lock knob switch in UNLOCK	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> Faulty driver's door lock knob switch Poor ground (G502) or an open in the ground wire An open or high resistance in the wire
		Driver's door lock knob switch in LOCK	Measure the voltage to ground: There should be about 5 V.	<ul style="list-style-type: none"> Faulty driver's door lock knob switch A short to ground in the wire
B22	BLU	Trunk lid open	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none"> Faulty trunk lid latch switch Poor ground (G701) or an open in the ground wire An open or high resistance in the wire
		Trunk lid closed	Measure the voltage to ground: There should be battery voltage.	<ul style="list-style-type: none"> Faulty trunk lid latch switch A short to ground in the wire

Cavity	Wire	Test condition	Test: Desired result	Possible cause if desired result is not obtained
P11	BRN	Ignition key inserted into the ignition key cylinder	Measure the voltage to ground: There should be less than 0.2 V.	<ul style="list-style-type: none">Faulty ignition key switchPoor ground (G503) or an open in the ground wireAn open or high resistance in the wire
		Ignition switch LOCK (0) position, and the ignition key removed from the ignition key cylinder	Measure the voltage to ground: There should be about 5 V.	<ul style="list-style-type: none">Faulty ignition key switchA short to ground in the wire