CVT System Component Location Index

TRANSMISSION
Removal and Installation
TRANSMISSION FLUID
Level Check
Replacement
TRANSMISSION FLUID PAN
Removal and Installation
DRIVE PLATE
Removal and Installation

TRANSMISSION RANGE SWITCH
Test
Removal and Installation

CVT SPEED SENSOR
Removal and Installation

POWERTRAIN CONTROL MODULE (PCM)
Update
Removal and Installation

INCLINATION SENSOR
(included in the VSA modulator-control unit)
Removal and Installation

TRANSMISSION FLUID WARMER
Removal and Installation

CVT DRIVE PULLEY SPEED SENSOR
Removal and Installation

TORQUE CONVERTER TURBINE SPEED SENSOR
Removal and Installation

CVT DRIVEN PULLEY PRESSURE SENSOR
Removal and Installation

VALVE BODY
Removal and Installation

CVT DRIVEN PULLEY PRESSURE CONTROL SOLENOID VALVE
Test
Removal and Installation

CVT CLUTCH PRESSURE CONTROL SOLENOID VALVE
Test
Removal and Installation

CVT DRIVE PULLEY PRESSURE CONTROL SOLENOID VALVE
Test
Removal and Installation

TRANSMISSION FLUID PUMP
Removal and Installation

SOLENOID WIRE HARNESS
Removal and Installation

CVT LOCK-UP CLUTCH CONTROL SOLENOID VALVE
Test
Removal and Installation

SHIFT SOLENOID VALVE B
Test
Removal and Installation

TRANSMISSION FLUID TEMPERATURE SENSOR
Test
Removal and Installation